

QUICK START GUIDE

PRO CLASSIC 6.5" SPEAKERS (PC410)

AQUATIC AV[®]
products with a watertight reputation

GETTING STARTED

Make sure your boat, ATV, vehicle, stereo, or amplifier is off during the installation process. Please read all installation instructions before beginning. If you have any questions, email us at support@aquaticav.com or use the Aquatic AV App. Customer support on the app is available Monday through Friday from 8 AM - 5 PM PST.

Contents

When first unpacking your new speaker, please check first that the package contains all the items below. If something is missing, contact the store where you purchased the product.

- One (1) pair of 6.5" Speakers
- Grill
- Four (4) mounting screws
- Four (4) stainless steel speed clips
- Quick Start Guide
- Warranty information
- Template

Tools Needed

- Electric drill
- Drill bit (sizes will vary based on surface material)
- Phillips screwdriver / Allen wrench
- Appropriate saw or utility knife to cut the surface material
- 18 AWG or larger speaker wire
- 2.5 mm and 5.2 female speaker spade connectors (*recommended*)
- Wire strippers (*optional*)
- Crimping tool (*optional*)
- Electric tool (*optional*)
- Marine sealant (*optional*)

Additional Accesories (sold separately)

- The Aquatic AV RGB Controller (RG100)
- RGB 12 ft Extension Cable (CB105)
- RGB 24 ft Extension Cable (CB106)
- RGB Y-Splitter (CB111)
- Universal Male RGB and Female Speaker Adapter Kit (CB112)

NOTE: For customized installations, additional tools and materials may be needed. Please visit an authorized Aquatic AV dealer before doing customized installations.

INSTALLATION

Mounting the Speakers

1. Please choose a mounting location with the following mounting considerations in mind.

NOTICE

During the installation of the Speaker, make sure to mount the speaker on a vertical surface. If mounted on a horizontal surface, water can be let in and deposit around the Speaker. This can harm the Speaker as time passes.

Make sure to turn off any power connection to the source unit, amplifier, or speakers during the installation process. Also check that the wires and connections are isolated from each other, not touching any surface. Otherwise, it can cause a short circuit, which may permanently damage the equipment and void the Product Warranty.

QUICK START GUIDE

PRO CLASSIC 6.5" SPEAKERS (PC410)

INSTALLATION (cont.)


2. Route the speaker wires (and LED wires, if applicable) from the source to the speaker location with good clearance for the wires.

Considerations While Wiring Your Speakers

- Speaker wires are not included with the speakers. You should use 18 AWG or larger speaker wires to connect the speakers to the stereo
- The leads on the speakers are terminated using make spade connectors. You should use female spade connectors (Not Included) to connect the speaker wire to the speaker leads for better connection


SPEAKER WIRE COLOR	SPEAKER WIRE POLARITY	SPADE CONNECTOR SIZE
White	Positive (+)	0.2" (5.20 mm)
White with a black stripe	Negative (-)	0.11" (2.8 mm)

3. Trim the template and make sure it fits in the selected location with enough depth and clearance
4. Using a drill bit appropriate for the mounting surface, drill a hole inside the dashed line on the template to prepare the mounting surface for cutting
5. Using a jigsaw or rotary tool, cut the mounting surface along the inside of the line on the template
6. Use a file and sandpaper to refine the size of the cutout if deemed necessary



NOTE: Do not over-tighten the screws, especially if the mounting surface is not flat. Bending the speaker frame can cause distortion.



Dimensions



QUICK START GUIDE

PRO CLASSIC 6.5" SPEAKERS
(PC410)

RGB CONFIGURATION



Universal Male RGB and Female Speaker Adapter Kit (CB112)

Get this kit to use our RGB speaker connector that allows to connect our RGB speakers with most RGB controllers that have red, blue, and green wires. Also included is our 4 PIN Speaker Wire Adapter that allows you to connect to any standard speaker wires.



QUICK START GUIDE

PRO CLASSIC 6.5" SPEAKERS
(PC410)

PRODUCT REGISTRATION

Register your new Aquatic AV product in order to receive a 2-year warranty. You will need proof of purchase, such as a receipt, from an authorized dealer. Additionally, you will have to provide your contact information, the date and location of the purchase, and the environment of the product (Marine, Harley, Spa, etc.).

You can submit a Product Registration form at the Aquatic AV Support Center or easily complete the registration process with the Aquatic AV App. The app is available on the App Store for iOS devices and on the Play Store for Androids.



WARRANTY

Aquatic AV offers a limited warranty of our products on the following terms:

Length of warranty

2 years on audio systems, electronics, speakers, and accessories (receipt required).

Coverage

This warranty covers only the original purchaser of an Aquatic AV product purchased from an authorized Aquatic AV dealer. In order to receive service, the purchaser must provide Aquatic AV with a copy of the receipt stating the customer name, dealer name, product purchased and date of purchase.

Defective products

Products found to be defective during the warranty period will be repaired or replaced (with a product deemed to be equivalent) at Aquatic AV's discretion.

What is not covered

- Damage caused by accident, abuse, improper operations or theft.
- Any cost or expense related to the removal or reinstallation of product.
- Service performed by anyone other than an authorized Aquatic AV service center.
- Any product with the serial number or tamper labels defaced, altered, or removed.
- Subsequent damage to other components.
- Any product not purchased from an authorized Aquatic AV dealer.

Limit on implied warranties

Any implied warranties including warranties of fitness for use and merchantability are limited in duration to the period of the express warranty set forth above. Some states do not allow limitations on the length of an implied warranty, so this limitation may not apply. No person is authorized to assume for Aquatic AV any other liability in connection with the sale of the product.

How to obtain service

You must obtain a return material authorization number (RMA) to return any product to Aquatic AV. You are responsible for shipping charges of returned products to Aquatic AV.

Please record the model and serial number[s] of your equipment in the space provided below as your permanent record and will assist us with your factory warranty coverage. These numbers can be found on the rear of the speaker.